

Macchina


ATVwth



Sezione

1

ATVwth\_part1



SerNo	PartNo	Description	Quantity
1	GB91-3.2x16	Cotter Pin 3.2x16	2
2	GB97.1-10	Plain Washer 10	21
3	AT120.111	Stick	1
4	AGL125.123	Fender	12
5	AGL125.124	Narrow Fender	1
6	GB5783-M12x30	Bolt M12x30	20
7	GB93-12	Spring Washer	9
8	EFGC125.115	Bearing Seat	2
9	UC207	Bearing UC207	2


10	AT120.026	Blade Axle	1
11	GB5782-M12x80	Bolt M12x80	28
12	AT120.118		
13	AT120.119		
14	GB889.1-M12	Lock Nut M12	40
15	GB13871-55x80x8	Oil Seal 55x80x8	1
16	AT120.116	Seal Bush	1
17	GB1152-M8x1	Grease Nipple M8x1	4
18	AT120.101	Lower Cover	1
19	GB5783-M6x12	Bolt M6x12	2
20	GB93-6	Spring Washer 6	2
21	GB97.1-6	Plain Washer 6	2
22	GB889.1-M8	Lock Nut M8	4
23	GB97.1-8	Plain Washer 8	12
24	AT120WD.012	Lower Cover Base	1
25	Z4-35x60	Power Lock Z4-35x60	1
26,1	AGL125.120	Small Pulley (ATV120 Two Groove)	1
26,2		Small Pulley (ATV145 Three Groove)	1
27	AT120.022	Right Skid	1
28	AT120WD.018	Mower Body	1
29	GB5783-M12x35	Bolt M12x35	4
30	AT120.021	Left Skid	1
31	AT120.013	Side Guard	2
32	AT120.104	Plug	2
33	6-DZM-14	Battery 6-DZM-14	1
34	AT120.131	Isolation Plate	1
35	AT120.132	Battery Cover	1
36	GB5782-M10x110	Bolt M10x110	2
37	JF420	Gasoline Engine	1
38	GB5783-M10x45	Bolt M10x45	4
39	GB889.1-M10	Lock Nut M10	5
40	GB/T1154-B1067	V Belt VB1067	2
41	AT120.024	Frame of Tension Pulley	1
42	GB893.1-47	Ring 47	1
43	GB278-303	Bearing 303-2Z	2
44	AT120.115	Tensioner Pulley	1
45	GB96-8	Plain Washer 8	1
46	GB5783-M8x20	Bolt M8x20	5
47	GB93-8	Spring Washer 8	9

48	AT120.109	Spring	1
49	AT120.012	Upper Cover Base	1
50	UNF 5/16-24X1	Bolt UNF 5/16-24x1	4
51	L100B2.001	Clutch Assembly	1
52	AT120.114	Spacer Washer	1
53	UNF 7/16-20x1.5	Bolt UNF 7/16-20x1.5	1
54	AT120.102	Upper Cover	1
55	AT120.020	Right Support Plate	1
56	GB2673-M8x25	Bolt M8x25	8
57	AGL125.113	Bearing Seat	2
58	UC205	Bearing UC205	2
59	AT120.025	Roller	1
60	AT120.110	Fender	1
61	AT120.019	Left Support Plate	1

Sezione

2

ATVwth\_part2




SerNo	PartNo	Description	Quantity
1	AT120.002	Pulled Frame Assembly	1
2	AT120WD.003	Mower Assembly	1
3	AT120W.011	Wheel Axle	2

4	GB278-205-2Z	Bearing 205-2Z	4
5	16x6.5-8	Tire 16x6.5-8	2
6	AT120.121	Bush	2
7	GB96-10	Big Washer 10	2
8	GB93-10	Spring Washer 10	2
9	GB5783-M10x25	Bolt M10x25	2
10	AT120.122	Dust Cover	2
11	GB889.1-M20	Lock Nut M20	2
12	GB97.1-20	Plain Washer 20	2
13	AT120W.101	Bush	2
14	AT120W.004	Handle Assembly	2
15	AT120WD.007	Back Door Assembly	1

Sezione

3


ATVwth\_part3



SerNo	PartNo	Description	Quantity
-------	--------	-------------	----------


1	AT120WD.011	Back Door Weldment	1
2	GB4141.26-CM12x16	Lift Handle	2
3	GB5783-M12x35	Bolt M12x35	3
4	GB889.1-M12	Lock Nut M12	5
5	GB5783-M12x40	Bolt M12x40	2

ATVwth\_part4



SerNo	PartNo	Description	Quantity
1	AT120.120	Handle Sleeve	2
2	AT120W.013	Handle	1
3	GB70.1-M8x35	Bolt M8x35	1
4	GB276-8104	Bearing 6004	1
5	GB1152-M6	Grease Nipple M6	1
6	AT120W.014	Outside Pipe	1
7	GB301-51104	Bearing 8104	1
8	AT120W.015	Screw Thread Rod	1
9	AT120W.016	Inside Pipe	1
10	GB5782-M12x70	Bolt M12x70	1
11	GB889.1-M12	Nut M12	1
12	GB894.1-20	Collar Ring 20	1

ATVwth\_part5



SerNo	PartNo	Description	Quantity
1	GB/T91-5x30	cotter pin 5X30	2
2	GB97.1-18	washer 18	2
3	AT120.108	rod	1
4	AT120.016	link plate weldment	1
5	GB5782-M16x80	bolt M16X80	1
6	AT120.106	pin	1
7	AT120.015	pulled pipe weldment	1
8	GB889.1-M16	lock nut M16	3
9	RP-3.2	R pin 3.2	1
10	AT120.017	adjuster	1
11	GB5782-M16x65	bolt M16X65	2
12	AT120.105	bush	2
13	AT120.014	link pipe	1
14	GB5782-M12x65	bolt M12X65	2
15	GB889.1-M12	lock nut M12	2
16	QT50	Trailer coupler 2"	1